




smorphi²

transforming learning with
transformer robots

assembly & info

(contents)

PART LIST	-----	(02)
BASIC ASSEMBLY TIPS	-----	(03)
SMORPHI ASSEMBLY		
A MECHANICAL	-----	(05)
B ELECTRONIC	-----	(22)
APP	-----	(41)
FURTHER EXPLORATION	-----	(44)

(part list)




All colors of parts are represented accurately here.

In the assembly steps, colors of some parts will be changed for diagram clarity.

8 x Acrylic Base Plate



4 x Aluminium Base Plate



8 x Base Skirt Panel A



8 x Base Skirt Panel B



8 x Mecanum Wheel (Right)



8 x Mecanum Wheel (Left)



16 x Mecanum Motor



16 x Motor Shaft Sleeve



16 x Motor Mount



6 x Solenoid



6 x Solenoid Latch Mount



6 x Solenoid Latch Guide



6 x Solenoid Catch



6 x Hinge Mount



3 x Hinge Mechanism



1 x Battery




2 x Battery bracket



1 x Masterboard (ESP32)



4 x Slaveboard



1 x Sound Sensor



1 x Temperature Sensor



4 x IR Sensor



1 x Husky Camera



1 x Husky Mount



10 x Sensor Lock



32 x Hex M-F M3 Nylon 45mm



28 x Hex F-F M3 Nylon 10mm



200 x Cap Screw M3x5



45 x Cap Screw M3x10



50 x Cap Screw M3x25



15 x Countersunk Screw M4x8



45 x Hex Nut M3




2 x Wing Screw M3x5




1 x USB-C Cable



8 x 4-pin Connector



4 x 8-pin Connector



1 x Battery Charger




1 x Ceramic Screwdriver CD-25



1 x HEX Key 1.5mm




1 x Husky Cam Cable
(included in huskycam package)




(basic assembly tips)

Symbols Used

-  Rotate Part
-  Assembly Path
-  Important Note
-  Sub-Assembly





smorphi^e
assembly start

A 1 (motor sub-assembly)



Motor Mount (16)



Motor Shaft Sleeve (16)



M3x22 (48)




DC Motor (16)




Left Mecanum Wheel (8)



Right Mecanum Wheel (8)




Left




Right



2 ways to differentiate between Left and Right Mecanum wheel
 - Look for L or R on the inside of the wheel
 - Left/Right wheel roller points up to Left/Right



x 16




x 8

=



x 8




x 8

=



x 8

A2 (base module sub-assembly)



AI Base Plate (4)



Hex M-F M3
45mm (16)



M3x5 (16)



M3x10 (45)




M3 Hex Nut (45)



Left Wheel SA (8)
from A.1







Right Wheel SA (8)
from A.1





Make sure that the numbers
are facing the right way up as
shown in the plan view above.



Before attaching each wheel,
check that the wheel is of the
correct orientation for each
numbered slot.







Base Skirt Panel A (8)




Base Skirt Panel B (8)




M3 x 5 (24)



plan view



x 4 =



x 4



A3 (solenoid latch sub-assembly)



Solenoid latch (6)






Solenoid latch mount (6)






Solenoid latch guide (6)





M3 x 5 (12)



A 4 (module 1 mechanical sub-assembly)







✕ Pay attention to the numbers and their positions in relation to the parts being attached.





✖ Check that the parts have been attached in the right location, in relation to the numbers.

A5 (module 2 mechanical sub-assembly)







✕ Pay attention to the numbers and their positions in relation to the parts being attached.





✕ Check that the parts have been attached in the right location.

A6 (module 3 mechanical sub-assembly)







✕ Pay attention to the numbers
 and their positions in relation to
 the parts being attached.





 Check that the parts have been attached in the right location, in relation to the numbers.

A7 (module 4 mechanical sub-assembly)




✕ Pay attention to the numbers
 and their positions in relation to
 the parts being attached.



✕ Check that the parts have been attached in the right location.

A8 (full mechanical assembly)



Module 1 (1)
from A.4

Module 2 (1)
from A.5

Module 3 (1)
from A.6

Module 4 (1)
from A.7

Hinge mechanism (3)

M4 x 8 (12)

Module 1

Module 2

Module 3





Module 4

M1

M2

M3


M4





plan view




Pay attention to the numbers and their orientation when attaching the modules together. Orientation of modules 3 and 4 are rotated 180° from modules 1 and 2.








x3



x3









Check all the positions of solenoids,
solenoid catches, hinge mounts before
proceeding to section B.





mechanical assembly completed

B 1 (e-tray sub-assembly)







✗ Make sure that you are attaching the slaveboards and not the masterboard.


✗ How to differentiate between masterboard and slaveboards:
- Masterboard has a special switch




B2 (e-tray onto mechanical assembly)





✂ Orientate e-tray SA and base module as shown on the right.
 Motor 1 connector on e-tray should be on top of Motor 1 of base module.
 Same goes for Motor 2, 3 and 4.




Before attaching the e-tray SA, please flip all the cables and connectors for motors and solenoids (not shown in diagram for clarity) out, for easy attachment later on.





✕ Orientation of modules 3 and 4 are rotated 180° from modules 1 and 2. Therefore, make sure that the e-tray SAs for module 3 and 4 are also rotated 180° to correspond to the motor orientation as numbered.




8 3 (all module motor cable connection)



To unplug cable:
Press and pull out
the connector




Note: Position of solenoid latch and solenoid catch is different for each module



✖ Make sure that Motor 1 is connected to Motor 1 connector on Slaveboard; the same goes for Motor 2, 3 and 4.

✖ Motor cable connection is the same for all 4 modules






Module 1 to 4


Motor Connection

Opening to pass wire through

B 4 (module 1 solenoid cable connection)







✕ Make sure to connect the solenoid to the labelled solenoid connector exactly as in the diagram below.




Opening to pass wire through

B5 (module 2 solenoid cable connection)





 Make sure to connect the solenoid to the labelled solenoid connector exactly as in the diagram below.




 Opening to pass wire through

B6 (module 3 solenoid cable connection)

-  solenoid cables (2)
attached to solenoids
-  module 3 SA (1)
attached to full assembly







 Make sure to connect the solenoid to the labelled solenoid connector exactly as in the diagram below.




Module 3
Solenoid Connection

 Opening to pass wire through

ⓑ 7 (module 4 solenoid cable connection)




✂ Make sure to connect the solenoid to the labelled solenoid connector exactly as in the diagram below.



Module 4
 Solenoid Connection



 Opening to pass wire through

8 (inter-module cable connection)





8-pin connectors (3)

full assembly (1)
from B.7




✕ Make sure the 8 pin connectors go around the HEXs that are on the same side as the hinge.




8 9 (address selection)



✂ Use the ceramic screwdriver to adjust the rotary switch and select the address for all 4 modules.
Module 1: Address 0, Module 2: Address 1,
Module 3: Address 2, Module 4: Address 3





B10 (masterboard e-tray sub-assembly)






✗ Make sure that you are attaching the masterboard and not the slaveboards.


✗ How to differentiate between masterboard and slaveboards:
- Masterboard has a special switch




B 11 (masterboard e-tray onto main assembly)



Align the header to slaveboard connector on the masterboard to face the side connecting Motor 1 and 4.



Opening to pass wire through



M2

B12 (attach acrylic covers)





Acrylic base plate (3)



full mechanical SA (1)
from B.11




M3 x 5 (12)




x 1

B13 (connect battery to masterboard)



B 14 (check connection)




✖ After checking that the lights are turned on, press on the enable button to activate the robot.

 electronic assembly completed

smorphi is ready!

next step: connect with app





1. App Download.




Not all devices are compatible now.

See the table below to check if your device is compatible with the Smorphi app.


Smorphi App Information	
Available Platforms	(Android)
Download from	(Google Play)
App Icon & Name	 smorphi
System Requirements	(Android 6+ Bluetooth 4.0+)
OS Requirements	

2. Bluetooth Connection. Turn on Smorphi and the Bluetooth of your smart device. Tap on Smorphi app icon to launch application.



After successful connection to paired smorphi, smorphi controls dashboard will appear.
See next page for the controls guide

3. Smorphi controls dashboard guide.



For tutorial to Smorphi activites and exercises, please refer to the online class exercises by following the link below:
<https://github.com/WefaaRobotics/Smorphi/wiki/>

(sensors)



sound sensor (x2)

Sound sensor measures volume of sound. Onboard potentiometer* can be used to tune the range of sensing. Possible applications: sound-triggered shape transformation or sound-triggered locomotion.




temperature sensor (x1)

Temperature sensor measures surrounding temperature, with a range of -55°C to 125°C.



IR sensor (x4)

IR sensors comes with 2 different modes, toggled by the switch onboard the sensor itself. One IR is front-facing and can be used to detect obstacles ahead. The other IR faces the ground and can be used for path tracking.





Husky camera (x1)

Husky Camera is an AI camera that is able to colour code, detect and track lines and intersections, and learn to detect objects taught to it.

✕ For sensor related activities and implementation, please refer to the online class exercises by following the link below:
<https://github.com/WefaaRobotics/Smorphi/wiki/Robot-Exercises>


* Tutorial on how to operate the potentiometer can be found by following the link below:
<https://github.com/WefaaRobotics/Smorphi/wiki/Exercise-6>

(sound/IR sensor wiring)




Module 1/2/3/4

Connect to masterboard or
slaveboard







Sound/IR sensor can be connected to any of the 6 sensor ports on the slaveboard (top) or any of the 4 sensor ports on the masterboard (bottom).

(temperature sensor wiring)




✕ Temperature sensors can only be connected to the masterboard.

(sensor position 1)




Sensors can be secured to the robot using the sensor lock provided.

(sensor position 2)




✕ Sensors can also be attached at the skirt panel of the robot.

(huskycam wiring)




(mounting the huskycam)




 Huskycam can be mounted on anywhere on the acrylic board.

(connect to laptop)



Plug in the USB-C cable as shown above to connect the motherboard to the computer. It allows us to upload our code from our computer onto the motherboard.

(charging)



✕ When battery is charging, an orange light will be shown on the charger. Once battery is fully charged, a green light will be shown

